

MOTORCYCLE DOCTOR LLC

Craig Silvers, Owner

 Date: 12-22-2017

www.MOTORCYCLEDOCTOR.com

craig@motorcycledoctor.com

Bucket Seat Stator Upgrade Kit HiSun 500-700

 Replace Stator with new 3 Wire Flat Plug (normal service manual procedure)
 Connect square White Plug and run the new Black Plug forward to Regulator. (using old stator, round plug, remove 3 spades)



2. Mount new Regulator inside center floorboard, right side angle 4" down from top. Place forward towards Sundry Box. Scribe marks to drill (2) 1/4" holes.









3. Route Red positive battery lead tight along the inside wall next to the metal water line. You may need to help push the wire though the skid pan holes. Route up the square frame tube and though the existing zip ties.











4. Locate battery positive post and install the Red ring terminal. Add Ground terminal to main ground engine tower.
Remove old regulator and seal that plug and zip tie to frame. Enjoy Extra Wattage!









