

HiSun UTV 500 / 700 and possible others need to have this electrical plug repaired or at least inspected and Di-Electrical grease applied



This will solve many hard to find Diagnostic Codes and ground issues like poor running & no spark.



Here is the location, between the front of the tank and front output drive shaft, close or on the skid pan.