




# Sector 550 & 750 Wire Diagram



# Sector 550 & 750 ECU Wire Diagram




# Sector 550 & 750 Ignition Wire Diagram





# Sector 550 & 750 Lighting Wire Diagram



- 1、 Battery parts
- 11、 The main relay assy.
- 24、 Head light assy. (L)
- 25、 Head light assy. (R)

# Sector 550 & 750 Signal Wire Diagram

