Power supply 电源供电+12V	→
Signal input 信号输入	→
Signal output 信号输出	→
GND	→

Indicate: efi cable components used in the wire line and the main cable wire, although part color is the same, but not between conduction, the only connection is that two eight hole plastic parts 注照：电喷电缆部件所用的导线与主电缆部件的导线虽然线色相同，但是两者之间不导通，唯一的连接是这两个八孔塑件

Acquisition speed signals and reverse, when the speed is more than 40 km/h, Or when the engine speed is greater than 4800 RPM, speed limiter to the ECU Square wave signal, the control of ignition and fuel injection
采集车速信号和倒档信号，当车速大于40km/h，或发动机转速大于4800rpm时，限速器向ECU发出方波信号，几几几几，控制点火和喷油

0.5mm²---0.05
1.25mm²---0.15
2.0mm²---2.0
3.0mm²---3.0
8.0mm²---4.0
14mm²---7.0

HS1000UTV-2

整车电器原理图

标记	处数	更改文件号	签字	日期
设 计				
审 核				
标准检查				
批 准				

所属装配号

图样标记	数量	重量	比例
S A			

共 页 第 页

重庆环松科技工业有限公司