



MOTORCYCLE DOCTOR LLC

Craig Silvers,
Owner

PO Box 1676 / 108 N. Business Rt. 5 Camdenton, Mo 65020
local; (573) 346-6867 fax; (573) 317-0011 toll free; (888) 346-6867

Date:
11-16-15

www.MotorcycleDoctor.com

Craig@MotorcycleDoctor.com

(for 2015 & Up Bench Seat UTV 500-1000)



The Brake Foot Pedal must have a small amount of free-play, approx 1/4". This allows the master cylinder plunger to return to its full closed position.

Simply remove the cotter pin and pivot pin. This allows you to remove and adjust the activator plunger pin to achieve the proper free play. Reassemble with a new cotter pin.



Loosen lock nut and adjust down tip. Tighten nut and check for proper free-play.

